













## Pin &amp; Sleeve










**INSULGRIP® Reversed Service Pin & Sleeve Devices Ordering Information**

30, 60, 100 and 200 Ampere, 600/250 Voltage AC/DC

**Ordering Information****Style I**

| Amps | Poles and Wires | Receptacle/ Connector Configuration   | Maximum Voltage AC/DC |  |              |              | Replacement Interiors    |           |
|------|-----------------|---|-----------------------|--|--------------|--------------|--------------------------|-----------|
|      |                 |   |                       | Receptacle   | Plug         | Connector    | Connectors & Receptacles | Plugs     |
| 30   | 2P 3W           |    | 600/250               | HBL330RS1WR  | HBL330PS1WR  | HBL330CS1WR  | IN330MS1                 | IN330FS1  |
| 30   | 3P 4W           |    | 600/250               | HBL430RS1WR  | HBL430PS1WR  | HBL430CS1WR  | IN430MS1                 | IN430FS1  |
| 30   | 4P 5W           |    | 600/250               | HBL530RS1WR  | HBL530PS1WR  | HBL530CS1WR  | IN530MS1                 | IN530FS1  |
| 60   | 2P 3W           |    | 600/250               | HBL360RS1WR  | HBL360PS1WR  | HBL360CS1WR  | IN360MS1                 | IN360FS1  |
| 60   | 3P 4W           |    | 600/250               | HBL460RS1WR  | HBL460PS1WR  | HBL460CS1WR  | IN460MS1                 | IN460FS1  |
| 60   | 4P 5W           |    | 600/250               | HBL560RS1WR  | HBL560PS1WR  | HBL560CS1WR  | IN560MS1                 | IN560FS1  |
| 100  | 2P 3W           |    | 600/250               | HBL3100RS1WR   | HBL3100PS1WR | HBL3100CS1WR | IN3100MS1                | IN3100FS1 |
| 100  | 3P 4W           |    | 600/250               | HBL4100RS1WR   | HBL4100PS1WR | HBL4100CS1WR | IN4100MS1                | IN4100FS1 |
| 100  | 4P 5W           |    | 600/250               | HBL5100RS1WR   | HBL5100PS1WR | HBL5100CS1WR | IN5100MS1                | IN5100FS1 |
| 200  | 3P 4W           |   | 600/250               | HBL4200RS1WR   | HBL4200PS1WR | HBL4200CS1WR | Consult Factory          |           |
| 200  | 4P 5W           |  | 600/250               | HBL5200RS1WR   | HBL5200PS1WR | HBL5200CS1WR | Consult Factory          |           |

**Style II**

| Amps | Poles and Wires | Receptacle/ Connector Configuration   | Maximum Voltage AC/DC |  |              |              | Replacement Interiors    |           |
|------|-----------------|---|-----------------------|--|--------------|--------------|--------------------------|-----------|
|      |                 |   |                       | Receptacle   | Plug         | Connector    | Connectors & Receptacles | Plugs     |
| 30   | 2P 3W           |  | 600/250               | HBL330RS2WR  | HBL330PS2WR  | HBL330CS2WR  | IN330MS2                 | IN330FS2  |
| 30   | 3P 4W           |  | 600/250               | HBL430RS2WR  | HBL430PS2WR  | HBL430CS2WR  | IN430MS2                 | IN430FS2  |
| 60   | 2P 3W           |  | 600/250               | HBL360RS2WR  | HBL360PS2WR  | HBL360CS2WR  | IN360MS2                 | IN360FS2  |
| 60   | 3P 4W           |  | 600/250               | HBL460RS2WR  | HBL460PS2WR  | HBL460CS2WR  | IN460MS2                 | IN460FS2  |
| 100  | 2P 3W           |  | 600/250               | HBL3100RS2WR   | HBL3100PS2WR | HBL3100CS2WR | IN3100MS2                | IN3100FS2 |
| 100  | 3P 4W           |  | 600/250               | HBL4100RS2WR   | HBL4100PS2WR | HBL4100CS2WR | IN4100MS2                | IN4100FS2 |
| 200  | 2P 3W           |  | 600/250               | HBL3200RS2WR   | HBL3200PS2WR | HBL3200CS2WR | Consult Factory          |           |
| 200  | 3P 4W           |  | 600/250               | HBL4200RS2WR   | HBL4200PS2WR | HBL4200CS2WR | Consult Factory          |           |

**Catalog Numbering System EXAMPLE: HBL430RS2WR**

| Manufacturer | No. of Wires                  | Amperage                               | Device Type                           | Grounding Style           | Environment              | Specialized        |
|--------------|-------------------------------|--|---------------------------------------|---------------------------|--------------------------|--------------------|
| HBL=Hubbell  | 3=2P 3W<br>4=3P 4W<br>5=4P 5W | 30=Amp<br>60=Amp<br>100=Amp<br>200=Amp | R=Receptacle<br>P=Plug<br>C=Connector | S1=Style I<br>S2=Style II | W=Watertight, UL Type 4X | R=Reversed Service |